

Vantage® HE

Gas-Fired, Low Intensity Unitary Heater Designed for Harsh Environments

Installation, Operation & Service Manual

HE-40
HE-60
HE-80
HE-100
HE-125
HE-150
HE-175

FOR YOUR SAFETY

If you smell gas:

1. Open windows.
2. DO NOT try to light any appliance.
3. DO NOT use electrical switches.
4. DO NOT use any telephone in your building.
5. Extinguish any open flame.
6. Leave the building.
7. Immediately call your local gas supplier after leaving the building. Follow the gas supplier's instructions.
8. If you cannot reach your gas supplier, call the Fire Department.

⚠ WARNING



Fire Hazard

Keep all flammable objects, liquids and vapors the minimum required clearances to combustibles away from heater.

Some objects will catch fire or explode when placed close to heater.

Failure to follow these instructions can result in death, injury or property damage.

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can result in death, injury or property damage. Read the Installation, Operation and Service Manual thoroughly before installing or servicing this equipment.

Installation must be done by a contractor qualified in the installation and service of gas-fired heating equipment or your gas supplier.

Installer

Please take the time to read and understand these instructions prior to any installation. Installer must give a copy of this manual to the owner.

Owner

Keep this manual in a safe place in order to provide your service technician with necessary information.



Roberts-Gordon LLC

1250 William Street
P.O. Box 44
Buffalo, New York 14240-0044
Telephone: +1.716.852.4400
Fax: +1.716.852.0854
Toll Free: 800.828.7450

www.robertsgordon.com

TABLE OF CONTENTS

SECTION 1: Heater Safety	1	SECTION 9: Gas Piping	43
1.1 Manpower Requirements	1	SECTION 10: Wiring	45
1.2 Safety Labels and Their Placement	1	10.1 Line Voltage Thermostat Wiring.....	45
1.3 California Proposition 65	1	10.2 Low Voltage Thermostat with One Burner	45
SECTION 2: Installer Responsibility	4	10.3 Low Voltage Thermostat Wiring with Multiple Burners.	46
2.1 Wall Tag	4	10.4 Electrical Connection to the Burner Box using Line	
2.2 Corrosive Chemicals.....	5	Voltage Thermostat on Control	46
2.3 National Standards and Applicable Codes	5	10.5 For External Thermostat Connection.....	47
SECTION 3: Clearances to Combustibles	6	10.6 Electrical Connection to Burner Box with Optional	
3.1 Required Clearances to Combustibles	6	External Low Voltage Thermostat.....	47
SECTION 4: National Standards and Applicable Codes ...	11	10.7 Internal Wiring.....	47
4.1 Gas Codes.....	11	10.8 Ladder Diagram	48
4.2 Aircraft Hangars	11	SECTION 11: Operation and Maintenance	49
4.3 Public Garages	11	11.1 Sequence of Operation	49
4.4 Electrical	11	11.2 To Shut Off Heater.....	49
4.5 Venting.....	11	11.3 To Start Heater	49
4.6 High Altitude	11	11.4 Pre-Season Maintenance and Annual Inspection....	49
SECTION 5: Major Components	12	11.5 Maintenance Checklist	50
5.1 Standard Parts List	13	SECTION 12: Troubleshooting	52
SECTION 6: Heater Installation	15	12.1 Honeywell SmartValve® II Troubleshooting	53
6.1 Outdoor Mounting.....	17	12.2 Troubleshooting Flow Chart	54
6.2 Burner Tube Installation	20	12.3 Manifold Gas Pressure Setting	56
6.3 Tube Clamp Package Installation.....	20	SECTION 13: Replacement Parts	57
6.4 Coupling and Tube Assembly.....	21	SECTION 14: General Specifications	60
6.5 Turbulator Installation	22	14.1 Material Specifications.....	60
6.6 Reflector Installation	23	14.2 Heater Specifications.....	60
6.7 Burner Installation.....	25	14.3 Suspension Specifications.....	60
SECTION 7: Optional Heater Accessories	26	14.4 Controls Specifications	60
7.1 U-Tube Configuration.....	26	SECTION 15: The ROBERTS GORDON® VANTAGE® HE War-	
7.2 Elbow Package Configuration.....	29	ranty	61
7.3 Reflector Side Extension (Not For Outdoor Use).....	31		
7.4 Lower Clearance Shield Installation (Not For Outdoor			
Use)	32		
7.5 Two-Foot Decorative Grille Installation (Not For Outdoor			
Use)	32		
7.6 Protective Grille Installation (Not For Outdoor Use)....	34		
SECTION 8: Venting	35		
8.1 General Venting Requirements.....	35		
8.2 Unvented Operation.....	36		
8.3 Horizontal Venting.....	36		
8.4 Vertical Venting	36		
8.5 Unvented Operation Tube Termination	36		
8.6 Length Requirements	36		
8.7 Venting Options	37		
8.8 Horizontal Ventilation 4" (10 cm) Pipe.....	38		
8.9 Vertical Ventilation 4" (10 cm) Pipe.....	38		
8.10 Common Sidewall Venting	39		
8.11 Common Vertical Venting	40		
8.12 Outside Combustion Air Supply	41		

© 2016 Roberts-Gordon LLC

All rights reserved. No part of this work covered by the copyrights herein may be reproduced or copied in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping or information storage and retrieval systems - without the written permission of Roberts-Gordon LLC.

TABLE OF FIGURES

LIST OF TABLES

Table 1: Contents of Heater Burner Carton	13
Table 2: Contents of Core and Extension Packages	13
Table 3: Component Package Guide.....	14
Figure 1: Top and Bottom Panel Label Placement	2
Figure 2: Side and Back Panel Label Placement.....	3
Figure 3: Standard Reflector	7
Figure 4: One Side Reflector.....	7
Figure 5: Two Side Reflectors	7
Figure 6: 45° Tilt Reflector	8
Figure 7: U-Tube, Standard Reflector.....	8
Figure 8: U-Tube, 45°	8
Figure 9: U-Tube, Opposite 45° Reflector	9
Figure 10: 2-Foot Deco Grille and Protective Grille	9
Figure 11: Lower Clearance Shield*	9
Figure 12: Venting	10
Figure 13: Major Component Descriptions.....	12
Figure 14: Critical Hanger Placement (Indoor Installation).....	16
Figure 15: Critical Hanger Placement (Outdoor Installation)...	17
Figure 16: Linear Heater Assembly Overview	18
Figure 17: Linear Heater Layout Overview.....	19
Figure 18: U-Tube Heater Assembly Overview	27
Figure 19: U-Tube heater Layout Overview	28
Figure 20: Reflector Joint Detail	30
Figure 21: Outdoor Vent Cap Installation.....	35
Figure 22: Tube Termination	36
Figure 23: Gas Connection with Flexible Gas Hose	44

SECTION 1: HEATER SAFETY



Your Safety is Important to Us!
This symbol is used throughout the manual to notify you of possible fire, electrical or burn hazards. Please pay special attention when reading and following the warnings in these sections.

Installation, service and annual inspection of heater must be done by a contractor qualified in the installation and service of gas-fired heating equipment.

Read this manual carefully before installation, operation or service of this equipment.

This heater is designed for heating nonresidential indoor or outdoor spaces. Do not install in residential spaces. This heater is not certified to meet the requirements of NFPA30A-2012 Section 7.6.6. (maximum tube temperature of 750 °F (399 °C)). Do not install this heater in facilities where compressed natural gas (CNG) or liquid natural gas (LNG) are present. These instructions, the layout drawing, local codes and ordinances, and applicable standards that apply to gas piping, electrical wiring, venting, etc. must be thoroughly understood before proceeding with the installation.

Protective gear is to be worn during installation, operation and service in accordance to the Occupational Safety and Hazard Administration (OSHA). Gear must be in accordance to NFPA 70E, latest revision when working with electrical components. Thin sheet metal parts have sharp edges. To prevent injury, the use of work gloves is recommended. The use of gloves will also prevent the transfer of body oils from the hands to the surface of the reflector.

Before installation, check that the local distribution conditions, nature of gas and pressure, and adjustment of the appliance are compatible.

This heater must be applied and operated under the general concepts of reasonable use and installed using best building practices.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do no play with the appliance.

and Service Manual, please contact Roberts-Gordon LLC.

1.1 Manpower Requirements

To prevent personal injury and damage to the heater, two persons will be required for installation.

1.2 Safety Labels and Their Placement

Product safety signs or labels should be replaced by the product user when they are no longer legible. Please contact Roberts-Gordon LLC or your ROBERTS GORDON® independent distributor to obtain replacement signs or labels. See *Page 2, Figure 1 through Page 3, Figure 2*.

1.3 California Proposition 65

In accordance with California Proposition 65 requirements, a warning label must be placed in a highly visible location on the outside of the equipment (i.e., near equipment's serial plate). See label placement drawing on *Page 2, Figure 1 through Page 3, Figure 2* for label location. Avoid placing label on areas with extreme heat, cold, corrosive chemicals or other elements. To order additional labels, please contact Roberts-Gordon LLC or your ROBERTS GORDON® independent distributor.

FIGURE 1: Top and Bottom Panel Label Placement

Bottom Panel

Top Panel

Logo Label

Rating Plate Label

Proposition 65 Label

Gas Connection Label

Description	Part Number
Logo Label	91013201
Rating Plate Label	91010401
Gas Connection Label	91018122
Proposition 65 Label	91070016

SECTION 2: INSTALLER RESPONSIBILITY

The installer is responsible for the following:

- To install the heater, as well as the gas and electrical supplies, in accordance with applicable specifications and codes. Roberts-Gordon LLC recommends the installer contact a Local Building inspector or Fire Marshal for guidance.
- To use the information given in a layout drawing and in the manual together with the cited codes and regulations to perform the installation.
- To install the heater in accordance with the clearances to combustibles.
- To furnish all needed materials not furnished as standard equipment.
- Plan location of supports. Locate a support near all elbows.
- To provide access to burners for servicing on all sides and for burner removal.
- To provide the owner with a copy of this installation, operation and service manual.
- To never use heater as support for a ladder or other access equipment and never hang or suspend anything from heater.
- To ensure there is adequate air circulation around the heater and to supply air for combustion, ventilation and distribution in accordance with local codes.
- To safely and adequately install heater using materials with a minimal working load of 75 lbs (33 kg).
- To ensure the heater is placed in an approved application.
- Be sure the heater has a downward pitch of 1/2" per 20' (1 cm per 6 m) away from the burner.
- A minimum of 10' (3 m) of tubing on HE-60/80 and a minimum of 15' (4.6 m) of tubing on HE-100/125/150/175 are required between the burner and the first elbow.
- Indoor hanging: Provide a suspension with vertical length of chain or swinging rod which has at least 2" (5 cm) of horizontal travel for each burner in a straight run. Be sure the suspension system is sufficiently flexible to accommodate thermal expansion, which occurs as the system heats up, *See Page 16, Figure 14.*
- Outdoor hanging: Chain should not be used when installing the unit outdoors. Use a suspension

system which minimizes the lateral movement or swing which might damage reflectors. *See Page 17, Figure 15.*

- Washbays/car washes: The heater must not be exposed to the direct spray from a pressure washer. To reduce the possibility of spray entering the burner, utilize an outside combustion air supply. *See Page 41, Section 8.13.*

The heater has been extensively tested under extreme conditions and is highly resistant to the outdoor elements. Care must be taken to design the proper hanging brackets and suspension (*See Page 17, Figure 15*) for the heater in high wind areas.

2.1 Wall Tag

A laminated wall tag is available for the heater as a permanent reminder of the safety instructions and the importance of the required clearances to combustibles. Please contact Roberts-Gordon LLC or your ROBERTS GORDON® independent distributor to obtain the wall tag. Affix the tag by peeling off the backing of the adhesive strips on the rear surface and position the tag on a wall near the heater's controls (e.g. thermostat or ROBERTS GORDON® Controller).

A copy of the wall tag (P/N 91037912) is illustrated on the back cover. For an immediate solution, you may affix this copy on the wall near the heater.

Know your model number and installed configuration. Model number and installed configuration are found on the burner and in the Installation, Operation and Service Manual. *See Page 7, Figure 3 through Page 10, Figure 12.* Write the proper clearance dimensions in permanent ink according to your model number and configuration in the open spaces on the tag.

2.2 Corrosive Chemicals

! CAUTION

Product Damage Hazard Do not use heater in area containing corrosive chemicals. Refer to appropriate Material Safety Data Sheets (MSDS). Failure to follow these instructions can result in product damage.


Roberts-Gordon LLC cannot be responsible for ensuring that all appropriate safety measures are undertaken prior to installation; this is entirely the responsibility of the installer. It is essential that the contractor, the sub-contractor, or the owner identifies the presence of combustible materials, corrosive chemicals or halogenated hydrocarbons* anywhere in the premises.

** **Halogenated Hydrocarbons** are a family of chemical compounds characterized by the presence of halogen elements (fluorine, chlorine, bromine, etc.). These compounds are frequently used in refrigerants, cleaning agents, solvents, etc. If these compounds enter the air supply of the burner, the life span of the heater components will be greatly reduced. An outside air supply must be provided to the burners whenever the presence of these compounds is suspected. Warranty will be invalid if the heater is exposed to halogenated hydrocarbons.*

2.3 National Standards and Applicable Codes

All appliances must be installed in accordance with the latest revision of the applicable standards and national codes. This refers also to the electric, gas and venting installation. Note: Additional standards for installations in Public Garages, Aircraft Hangars, etc. may be applicable.

SECTION 3: CLEARANCES TO COMBUSTIBLES**3.1 Required Clearances to Combustibles**

! WARNING

Fire Hazard
Keep all flammable objects, liquids and vapors the minimum required clearances to combustibles away from heater.
Some objects will catch fire or explode when placed close to heater.
Failure to follow these instructions can result in death, injury or property damage.

Clearances are the required distances that combustible objects must be away from the heater to prevent serious fire hazards. Combustibles are materials that may catch on fire and include common items such as wood, paper, rubber, fabric, etc. **Maintain clearances to combustibles at all times for safety.**

Clearances for all heater models are located on the burner of the heater and *on Page 7, Figure 3 through Page 10, Figure 12* in this manual. Check the clearances on each burner for the model heater being installed to make sure the product is suitable for your application and the clearances are maintained. Read and follow the safety guidelines below:

- Keep gasoline or other combustible materials including flammable objects, liquids, dust or vapors away from this heater or any other appliance.
- The stated clearances to combustibles represents a surface temperature of 90° F (50°C) above room temperature. Building materials with a low heat tolerance (such as plastics, vinyl siding, canvas, triply, etc) may be subject to degradation at lower temperatures. It is the installer's responsibility to assure that adjacent materials are protected from degradation.
- Maintain clearances from heat sensitive equipment and workstations.
- Maintain clearances from vehicles parked below the heater.

- Maintain clearances from swinging and overhead doors, overhead cranes, vehicle lifts, partitions, storage racks, hoists, building construction, etc.
- In locations used for the storage of combustible materials, signs must be posted to specify the maximum permissible stacking height to maintain required clearances from the heater to the combustibles. Signs must be posted adjacent to the heater thermostat. In the absence of a thermostat, signs must be posted in a conspicuous location.
- Consult local Fire Marshal, Fire Insurance Carrier or other authorities for approval of proposed installation when there is a possibility of exposure to combustible airborne materials or vapors.
- Hang heater in accordance to the minimum suspension requirements *on Page 16, Figure 14*.
- If the radiant tubes must pass through the building structure, be sure that adequate sleeving and fire stop is installed to prevent scorching and/or fire hazard.

- NOTE:** 1. All dimensions are from the surfaces of all tubes, couplings and elbows.
 2. Clearances B, C and D can be reduced by 50% after 25' (7.5 m) of tubing downstream from where the burner and burner tube connect.

FIGURE 3: STANDARD REFLECTOR


	Model	(inches)				(centimeters)			
		A	B	C	D	A	B	C	D
	HE-40	6	27	53	27	16	69	135	69
	HE-60	6	35	63	35	16	89	161	89
	HE-80	6	38	66	38	16	97	168	97
	HE-100	6	40	71	40	16	102	181	102
	HE-125	6	46	77	46	16	117	196	117
	HE-150	6	50	80	50	16	127	204	127
	HE-175	8	52	82	52	21	133	209	133

FIGURE 4: ONE SIDE REFLECTOR



	Model	(inches)				(centimeters)			
		A	B	C	D	A	B	C	D
	HE-40	6	9	53	44	16	23	135	112
	HE-60	6	9	63	47	16	23	161	120
	HE-80	6	9	70	54	16	23	178	138
	HE-100	6	9	77	59	16	23	196	150
	HE-125	6	9	83	65	16	23	211	166
	HE-150	6	9	86	69	16	23	219	176
	HE-175	8	9	88	73	21	23	224	186

FIGURE 5: TWO SIDE REFLECTORS

	Model	(inches)				(centimeters)			
		A	B	C	D	A	B	C	D
	HE-40	6	15	53	15	16	39	135	39
	HE-60	6	23	66	23	16	59	168	59
	HE-80	6	25	72	25	16	64	183	64
	HE-100	6	27	78	27	16	69	199	69
	HE-125	6	32	84	32	16	82	214	82
	HE-150	6	35	88	35	16	89	224	89
	HE-175	8	40	91	40	21	102	232	102

NOTE: 1. All dimensions are from the surfaces of all tubes, couplings and elbows.
 2. Clearances B, C and D can be reduced by 50% after 25' (7.5 m) of tubing downstream from where the burner and burner tube connect.

FIGURE 6: 45° TILT REFLECTOR

Model	(inches)				(centimeters)			
	A	B	C	D	A	B	C	D
HE-40	8	8	51	46	21	21	130	117
HE-60	8	8	60	54	21	21	153	138
HE-80	8	8	66	60	21	21	168	153
HE-100	10	8	74	64	26	21	188	163
HE-125	10	8	78	69	26	21	199	176
HE-150	12	8	84	74	31	21	214	188
HE-175	12	8	85	79	31	21	216	201

FIGURE 7: U-TUBE, STANDARD REFLECTOR

Model	(inches)				(centimeters)			
	A	B	C	D	A	B	C	D
HE-40	- UNAPPROVED -				- UNAPPROVED -			
HE-60	6	35	63	30	16	89	161	77
HE-80	6	38	69	37	16	97	176	94
HE-100	6	40	76	39	16	102	194	100
HE-125	6	46	79	43	16	117	201	110
HE-150	6	50	84	47	16	127	214	120
HE-175	8	54	87	51	21	138	221	130

FIGURE 8: U-TUBE, 45°

Model	(inches)				(centimeters)			
	A	B	C	D	A	B	C	D
HE-40	- UNAPPROVED -				- UNAPPROVED -			
HE-60	8	8	60	42	21	21	153	107
HE-80	8	8	66	46	21	21	168	117
HE-100	8	8	74	52	21	21	188	133
HE-125	8	8	78	61	21	21	199	155
HE-150	8	8	84	66	21	21	214	168
HE-175	8	8	85	70	21	21	216	178

- NOTE:** 1. All dimensions are from the surfaces of all tubes, couplings and elbows.
 2. Clearances B, C and D can be reduced by 50% after 25' (7.5 m) of tubing downstream from where the burner and burner tube connect.

FIGURE 9: U-TUBE, OPPOSITE 45° REFLECTOR


	Model	(inches)				(centimeters)			
		A	B	C	D	A	B	C	D
	HE-40	- UNAPPROVED -				- UNAPPROVED -			
	HE-60	8	54	60	22	21	138	153	56
	HE-80	8	60	66	22	21	153	168	56
	HE-100	10	64	74	22	26	163	188	56
	HE-125	10	70	78	22	26	178	199	56
	HE-150	12	74	84	22	31	188	214	56
	HE-175	12	76	85	22	31	194	216	56

FIGURE 10: 2-FOOT DECO GRILLE AND PROTECTIVE GRILLE



	Model	(inches)				(centimeters)			
		A	B	C	D	A	B	C	D
	HE-40	6	27	53	27	16	69	135	69
	HE-60	6	35	63	35	16	89	161	89
	HE-80	6	38	66	38	16	97	168	97
	HE-100	6	40	71	40	16	102	181	102
	HE-125	6	46	77	46	16	117	196	117
	HE-150	6	50	80	50	16	127	204	127
	HE-175	8	52	82	52	21	133	209	133

FIGURE 11: LOWER CLEARANCE SHIELD*

	Model	(inches)				(centimeters)			
		A	B	C	D	A	B	C	D
	HE-40	6	34	27	34	16	87	69	87
	HE-60	6	39	33	39	16	100	84	100
	HE-80	6	40	38	40	16	102	97	102
	HE-100	6	50	44	50	16	127	112	127
	HE-125	6	54	48	54	16	138	122	138
	HE-150	6	55	50	55	16	140	127	140
	HE-175	- UNAPPROVED -				- UNAPPROVED -			

*When installed in the first 10' (3 m).

NOTE: 1. All dimensions are from the surfaces of all tubes, couplings and elbows.
 2. Clearances B, C and D can be reduced by 50% after 25' (7.5 m) of tubing downstream from where the burner and burner tube connect.

FIGURE 12: VENTING

	Model	(inches)			(centimeters)		
		A	E	F	A	E	F
	HE-40	14	18	18	36	46	46
	HE-60	14	18	18	36	46	46
	HE-80	20	24	18	51	61	46
	HE-100	20	24	18	51	61	46
	HE-125	20	24	18	51	61	46
	HE-150	20	30	18	51	77	46
	HE-175	20	30	18	51	77	46

SECTION 4: NATIONAL STANDARDS AND APPLICABLE CODES

4.1 Gas Codes

The type of gas appearing on the nameplate must be the type of gas used. Installation must comply with national and local codes and requirements of the local gas company.

United States: Refer to National Fuel Gas Code NFPA 54/ANSI Z223.1 - latest revision.

Canada: Refer to Natural Gas and Propane Installation Code CSA B149.1 - latest revision.

4.2 Aircraft Hangars

Installation in aircraft hangars must be in accordance with the following codes:

United States: Refer to Standard for Aircraft Hangars, NFPA 409 - latest revision.

Canada: Refer to Natural Gas and Propane Installation Code CSA B149.1 - latest revision.

In aircraft storage and servicing areas, heaters shall be installed at least 10' (3 m) above the upper surface of wings or of engine enclosures of the highest aircraft which may be housed in the hangar. The measurement shall be made from the wing or engine enclosure (whichever is higher from the floor) to the bottom of the heater.

- In shops, offices and other sections of aircraft hangars communicating with aircraft storage or servicing areas, heaters shall be installed not less than 8' (2.4 m) above the floor.
- Suspended or elevated heaters shall be so located in all spaces of aircraft hangars that they shall not be subject to injury by aircraft, cranes, movable scaffolding or other objects. Provisions shall be made to assure accessibility to suspended heaters for recurrent maintenance purposes.

4.3 Public Garages

Installation in garages must be in accordance with the following codes:

United States: Refer to Standard for Parking Structures NFPA 88A - latest revision or the Code for Motor Fuel Dispensing Facilities and Repair Garages, NFPA 30A - latest revision.
Canada: Refer to Natural Gas and Propane Installation Code CSA B149.1 - latest revision.

- Heaters must not be installed less than 8' (2.4 m) above the floor. Minimum clearances to combustibles must be maintained from vehicles parked below the heater.
- When installed over hoists, minimum clearances to combustibles must be maintained from the upper most point of objects on the hoist.

4.4 Electrical

The heater must be electrically grounded in accordance with the following codes:

United States: Refer to National Electrical Code®, NFPA 70 - latest revision. Wiring must conform to the most current National Electrical Code®, local ordinances and any special diagrams furnished.

Canada: Refer to Canadian Electrical Code, CSA C22.1 Part 1 - latest revision.

4.5 Venting

The venting must be installed in accordance with the requirements within this manual and the following codes:

United States: Refer to National Fuel Gas Code NFPA 54/ANSI Z223.1 - latest revision.













Canada: Refer to Natural Gas and Propane Installation Code CSA B149.1 - latest revision.

4.6 High Altitude

These heaters are approved for installations up to 2000' (610 m)(US), 4500' (1370 m)(Canada) without modification. Consult factory if US installation is above 2000' (610 m) or Canadian installation is above 4500' (1370 m).

SECTION 5: MAJOR COMPONENTS

FIGURE 13: Major Component Descriptions

 <p>Burner with Tube Gasket Must be installed with the flame observation window facing down.</p>	 <p>Reflector (Stainless Steel or Aluminum) Alternate overlap as shown on overview and on Page 19, Figure 17. Minimum overlap is 6" (16 cm).</p>
 <p>Burner Tube Supplied in 10' (3 m) lengths. Burner tube is always the first tube after the burner.</p>	 <p>Vent Cap Attach at flue end and air inlet with vent adapter, where required.</p> <p>Tube Heat Treated Aluminized tube supplied in 10' (3 m) lengths.</p>
 <p>Tube and Reflector Hanger with Clamp Package Position this hanger no more than 4" (10 cm) away from the burner.</p>	 <p>Coupling Assembly with Lock</p>
 <p>Tube and Reflector Hanger Suspend system from these hangers.</p>	 <p>Reflector End Cap Punch out center section to accommodate tube.</p>
 <p>Reflector Support Strap & Wire Form</p>	 <p>Vent Adapter</p>
 <p>Vinyl Coated Flex Gas Line with Shut Off Cock</p>	 <p>Turbulator Install turbulator as specified in the turbulator installation chart. See Page 22, Section 6.5. Turbulator is not required on the HE-125/150/175.</p>

5.1 Standard Parts List

Table 1: Contents of Heater Burner Carton

Part No.	Description	HE-40	HE-60	HE-80	HE-100	HE-125	HE-150	HE-175
032XXXXX	Burner Assembly (Rate and Fuel Varies)	1	1	1	1	1	1	1
02568200	Gasket (Burner to Burner Tube)	1	1	1	1	1	1	1
132100NA	Installation, Operation and Service Manual	1	1	1	1	1	1	1
94273914	Hex Head Bolts 5/16-18 Rolok	4	4	4	4	4	4	4
96411600	Split Lock washer	4	4	4	4	4	4	4
91221100	Nipple 1/2" NPT x 4" Galv.	1	1	1	1	1	1	1
91317300	1/4" Quick Disconnect (Wire)	2	2	2	2	2	2	2
*91412204	Vinyl Coated Flexible Gas Connector Assembly - 3/4" NPT	1	1	1	1	1	1	1
03051503	Turbulator Adapter	1	1	1	1	-	-	-
03051504	Turbulator Aluminized Steel	2	4	4	2	-	-	-
03051505	Turbulator Stainless Steel	1	-	-	-	-	-	-

*Canadian Models: Rubber (Type 1) Gas Hoses available as an accessory. See Page 43, Section 9.

Table 2: Contents of Core and Extension Packages

Part No.	Description	Core Packages								Extension Packages							
		Aluminized with Aluminum Reflector				Aluminized with Stainless Steel Reflector				Aluminized with Aluminum Reflector				Aluminized with Stainless Steel Reflector			
		10' (3 m)	20' (6 m)	30' (9 m)	40' (12 m)	10' (3 m)	20' (6 m)	30' (9 m)	40' (12 m)	10' (3 m)	20' (6 m)	30' (9 m)	40' (12 m)	10' (3 m)	20' (6 m)	30' (9 m)	40' (12 m)
91409408	Tube, HT Aluminized, 10' (3 m)	-	1	2	3	-	1	2	3	1	2	3	4	1	2	3	4
03051101	Burner Tube, ALUMI-THERM® Steel, 10' (3 m)	-	-	1	1	-	-	-	-	-	-	-	-	-	-	-	-
03051102	Burner Tube, ALUMI-THERM® Steel, 10' (3 m)	-	-	-	-	-	-	1	1	-	-	-	-	-	-	-	-
03051601	Burner Tube, HT ALUMI-THERM® Steel, 10' (3 m)	1	1	-	-	-	-	-	-	-	-	-	-	-	-	-	-
03051602	Burner Tube, HT ALUMI-THERM® Steel - HE, 10' (3m)	-	-	-	-	1	1	-	-	-	-	-	-	-	-	-	-
01312700	Coupling Assembly	-	1	2	3	-	1	2	3	1	2	3	4	1	2	3	4
02750303	Standard Reflector, 8' (3.5 m)	2	3	4	6	-	-	-	-	2	3	4	6	-	-	-	-
027503SS*	Stainless Steel Reflector, 8' (3.5 m)	-	-	-	-	2	3	4	6	-	-	-	-	2	3	4	6
02750800	End Cap	2	2	2	2	-	-	-	-	-	-	-	-	-	-	-	-
027508SH*	Stainless Steel End Cap with Hole	-	-	-	-	2	2	2	2	-	-	-	-	-	-	-	-
03090100	Tube and Reflector Hanger	2	3	4	5	2	3	4	5	1	2	3	4	1	2	3	4
91907302	S-Hook	2	3	4	5	2	3	4	5	1	2	3	4	1	2	3	4
03050010	Reflector Support Package (Strap, Wire Form, Screws)	1	2	3	5	2	4	5	7	2	3	4	6	2	3	4	6
91107720	U-Clip Package	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
90502700	Vent Adapter	1	1	1	1	1	1	1	1	-	-	-	-	-	-	-	-
01318901	Tube Clamp Package	1	1	1	1	2	2	2	2	-	-	-	-	-	-	-	-
	Part Number	CP10ALUM	CP20ALUM	CP30ALUM	CP40ALUM	CP10ALUMSS	CP20ALUMSS	CP30ALUMSS	CP40ALUMSS	EXP10ALUM	EXP20ALUM	EXP30ALUM	EXP40ALUM	EXP10ALUMSS	EXP20ALUMSS	EXP30ALUMSS	EXP40ALUMSS

* Optional with the aluminized core package.

Table 3: Component Package Guide

Model	Tubing Length	Core and Extension Packages	
		Aluminized	Stainless Steel
HE-40	10' (3 m)	CP10ALUM	CP10ALUMSS
HE-60	20' (6 m)	CP20ALUM	CP20ALUMSS
HE-80	20' (6 m)	CP20ALUM	CP20ALUMSS
HE-100	30' (9 m)	CP30ALUM	CP30ALUMSS
HE-125	40' (12 m)	CP40ALUM	CP40ALUMSS
HE-150	50' (15 m)	CP30ALUM + EXP20ALUM	CP30ALUMSS+ EXP20ALUMSS
HE-175	60' (18 m)	CP30ALUM + EXP30ALUM	CP30ALUMSS + EXP30ALUMSS

Table 4: Accessories Package (03200001)

Part No.	Description	Quantity
90502300	4" Metalbestos Vent Cap	2
90502700	Vent Adapter	1

Additional tubing length may be added to heater. Tubing must be heat-treated, aluminized or porcelain coated. Any additional tubing lengths are considered as vent length for length determination. Maximum venting length for minimum heater length is 45' (13.7 m) total.

SECTION 6: HEATER INSTALLATION**⚠ WARNING****Severe Injury Hazard**

Secure burner to burner tube with bolts and lockwashers.

Hang heater with materials with a minimum working load of 75 lbs (33 kg).

Failure to follow these instructions can result in death, injury or property damage.

Expansion and contraction of the tube dictates that the minimum suspension lengths in the table on Page 16, Figure 14 be maintained.

⚠ WARNING**Cut/Pinch Hazard**

Wear protective gear during installation, operation and service.

Edges are sharp.

Failure to follow these instructions can result in injury.

To ensure your safety, and comply with the terms of the warranty, all units must be installed in accordance with these instructions.

The gas or the electrical supply lines must not be used to support the heater.

Do not locate the gas or electric supply lines directly over the path of the flue products from the heater.


The heater must be installed in a location that is readily accessible for servicing.

The heaters must be installed in accordance with clearances to combustibles as indicated on the rating plate and in this instruction manual.

The minimum and maximum gas inlet pressures must be maintained as indicated on the rating plate.

Typical installation configurations are shown in Figure 14.

FIGURE 14: Critical Hanger Placement (Indoor Installation)



6.1 Outdoor Mounting

The heater is meant for stationary mounting in all situations and should not be suspended from any structure which may become mobile or from any organic structures such as trees. Clearances to combustibles must be maintained in all cases; do not install heaters in a location such as a parking area, where a vehicle with a painted or non-metallic upper surface,

may be parked within the clearances to combustibles. See Page 17, Figure 15.

The bottom of the combustion air inlet shall not be less than 12" (30 cm) above a surface which could support snow, ice, or debris.

FIGURE 15: Critical Hanger Placement (Outdoor Installation)






FIGURE 17: Linear Heater Layout Overview



Step 6.2 Burner Tube Installation

Hanging hardware shown is for indoor installation only. See Page 17, Figure 15 for outdoor suspension details.


NOTE:
Tubing requires a downward slope of 1/2" (1.3 cm) per 20' (6 m) away from burner.



Description	Part Number
Burner Tube	03051XXX
S-Hook	91907302
Tube/Reflector Hanger	03090100

Step 6.3 Tube Clamp Package Installation


Hanging hardware shown is for indoor installation only. See Page 17, Figure 15 for outdoor suspension details.




Description	Part Number
Tube Clamp Package	01318901
Tube Clamp	01396801
Bolt	97113940
Flat Washer	95211600
Nut	92113900

Step 6.4 Coupling and Tube Assembly


A Close coupling with tab




B Start Slide bar/Coupling Lock onto coupling



C Insert tubes into coupling




D Tighten coupling to join tubes



Description	Part Number
Coupling	01329600
Slide bar/Coupling Lock	01329700
Tube	91409XXX

Step 6.4.1 Coupling and Tube Assembly (Continued)

Tighten slide bar as shown below



- Repeat Step 6.4 A - D until all tubes are assembled. See Page 22, Section 6.4.2.

Step 6.4.2 Coupling and Tube Assembly (Continued)

Model	Tube Length
HE-40	10' (3 m)
HE-60	20' (6 m)
HE-80	20' (6 m)
HE-100	30' (9 m)
HE-125	40' (12 m)
HE-150	50' (15 m)
HE-175	60' (18 m)

Hanging hardware shown is for indoor installation only. See Page 17, Figure 15 for outdoor suspension details.

Step 6.5 Turbulator Installation

Install turbulator as specified in the turbulator installation chart below. Turbulator is not required on the HE-125/150/175

Turbulator Installation	
Model	Tube Section
HE-40	1st 10' Section
HE-60	2nd 10' Section
HE-80	2nd 10' Section
HE-100	3rd 10' Section
HE-125	N/A
HE-150	N/A
HE-175	N/A

Description	Part Number
Turbulator Adapter	03051503
Turbulator Section	03051504
Turbulator Section (Stainless)	03051505
Tube	91409XXX

Turbulator Section (stainless) used in HE-40 heaters must be in the section of tube nearest to the burner.

Fold tab around outside of tube nearest to the vent to hold turbulator in place.

Step 6.6 Reflector Installation


⚠ WARNING**Fire Hazard**

Support reflector with reflector hanger and support strap.

Reflector must not touch tube.

Failure to follow these instructions can result in death, injury or property damage.

NOTE: All tube surfaces must be covered by a reflector, except for a U-Tube. Hanging hardware shown is for indoor installation only. See Page 17, Figure 15 for outdoor suspension details.



Description	Part Number
Tube/Reflector Hanger	03090100
Burner Tube	03051XXX
Reflector 96" (244 cm)	02750303

Step 6.6.1 Reflector, U-Clip and Reflector Support Installation




The pictorial drawings of the heater construction in Section 6 are schematic only and provide a general guideline of where hangers, reflector supports and U-clips are to be installed.

tor supports and U-clips depends on the individual installation. Use either pop rivets or sheet metal screws instead of u-clips when installing end caps and joint pieces in areas where impact and high wind may be a factor. The following rules must be observed.

To ensure proper expansion and contraction movement of the reflectors, a combination of U-clips and reflector supports are used. The positioning of reflector

Hanging hardware shown is for indoor installation only. See Page 17, Figure 15 for outdoor suspension details.

1. The first reflector after the burner must be affixed in the middle of the reflector with a reflector support and tight screws.




Overlap must be a minimum of 6" (16 cm).

2. The overlap at the first and second reflector is a **slip overlap**. Thereafter, every third reflector joint is a slip overlap. A slip overlap is achieved by either:
 - a.) both reflectors lay inside a hanger.

(No reflector support needed.)


- b.) using a reflector support with loose screws at the reflector overlap.



3. The remaining reflector overlaps require a **non-slip overlap** connection. To affix the reflectors together in a non-slip overlap either:
 - a.) use reflector support and tight screws.

- b.) if both reflectors lay inside a hanger, u-clips or sheet metal screws may be used.


This section of three reflectors joined together must be affixed to the tube with at least one reflector support with tight screws.



Description	Part Number
Reflector Support Package	03050010
Wire Form	91908004
Reflector Support Strap	03050000
Screw #8 x 3/4	94320812
U-Clip Package	91107720
Reflector End Cap	027508XX

Step 6.7 Burner Installation

Hanging hardware shown is for indoor installation only. See Page 17, Figure 15 for outdoor suspension details.



Description	Part Number
Bolt	94273914
Burner	032XXXXX
Lock Washer	96411600
Gasket	02568200

SECTION 7: OPTIONAL HEATER ACCESSORIES

! WARNING

Cut/Pinch Hazard
Wear protective gear during installation, operation and service.
Edges are sharp.
Failure to follow these instructions can result in injury.

7.1 U-Tube Configuration

Heaters (except HE-40) are approved for optional U-Tube configurations.

The U-Tube may be installed in either a standard horizontal position, a 45° position or in an opposite 45° position as shown on *Page 8, Figure 7 through Figure 9*. When using a U-Tube configuration, the following additional rules must be adhered to:

- A minimum of 10' (3 m) on HE-60/80 and a minimum of 15' (4.5 m) on HE-100/125/150/175 is required between the burner and the U-Tube.
- The correct turbulator (See *Page 22, Figure 6.5*) must be installed in the last standard section of tube.
- The burner must never be operated in a tilted position.
- The heater must be properly supported at all locations. See *Page 28, Figure 19*.

FIGURE 18: U-Tube Heater Assembly Overview











FIGURE 19: U-Tube heater Layout Overview

LEGEND	
	Burner
	Reflector
	Tube 10' (3 m)
	Tube 5' (1.5 m)**
	Tube/Reflector Hanger
	Coupling Assembly
	U-tube

a = 14" (36 cm)
reflector width (not shown)

b = 2" (5 cm)
end cap to burner

c = 2" (5 cm)
end cap to hanger

d = 7'6" (2.3 m)
distance first hanger

e = 10' (3 m)
distance between hangers






f = 5' (1.5 m)
distance between last full tube hanger and half tube hanger

g = 17.5" (44 cm)
burner height

h = 9.5" (24 cm)
burner height

*Requires the last **reflector** before the u-tube to be cut in half for use on both sides.

Requires the last **tube before the u-tube to be cut in half for use on both sides.




7.2 Elbow Package Configuration

Step 7.2.1 Elbow Installation


Description	Part Number
Elbow Package	02718702
90° Elbow	01335801
Coupling	01312700
Reflector End Cap	02750800
Reflector Joint Piece	02750900
U-Clip Package	91107720

Minimum Distance Required Between Burner and Elbow	
Model	Minimum Distance
HE-40	10' (3 m)
HE-60	10' (3 m)
HE-80	10' (3 m)
HE-100	15' (4.5 m)
HE-125	15' (4.5 m)
HE-150	15' (4.5 m)
HE-175	15' (4.5 m)


Step 7.2.2 Elbow Installation



Step 7.2.3 Reflector Joint Installation



Step 7.2.4 Reflector Joint Installation



Step 7.2.5 Reflector Joint Detail






FIGURE 20: Reflector Joint Detail




7.3 Reflector Side Extension (Not For Outdoor Use)

Step 7.3.1 Bracket Installation



Step 7.3.2 Side Reflector Installation



7.4 Lower Clearance Shield Installation (Not For Outdoor Use)

Step 7.4.1 Shield Support Strap Assembly


Description	Part Number
Lower Clearance Shield Package	01397501
Shield Support Strap	01397500
Lower Clearance Shield 8' (2.4 m)	02793000
Locknut #8	92311400
Flat Washer #8	95310800
Screw #8 x 3/8"	93511406

7.5 Two-Foot Decorative Grille Installation (Not For Outdoor Use)

Step 7.5.1 Grille Installation

Description	Part Number
Aluminium Grille 2' x 4' (.6m x 1.2m)	91407000


Step 7.5.2 Frame Shield Installation



Description	Part Number
Deco Grille Shield	01365900

Step 7.5.3 Reflector Side Extension Installation for Decorative Grilles

NOTE: If the decorative grille system is to be installed in an area with considerable air movement, it is recommended that one #8 x 3/8" sheet metal screw be installed per reflector extension to prevent it from blowing over.




Distance "A"		Extension	
Minimum	Maximum	Part No.	Width
2" (4 cm)	6" (15 cm)	01370408	8" (20 cm)
6" (15 cm)	10" (26 cm)	01370412	12" (30 cm)
10" (26 cm)	14" (37 cm)	01370416	16" (40 cm)


Description	Part Number
Reflector Side Extension 48" (122 cm)	01370412

7.6 Protective Grille Installation (Not For Outdoor Use)


Step 7.6.1 Silicone Cap Installation




Step 7.6.2 Grille End Cap Installation



Step 7.6.3 Grille Installation



SECTION 8: VENTING

⚠ WARNING

Carbon Monoxide Hazard
Heaters installed unvented must be interlocked with sufficient building exhaust.
Heaters must be installed according to the installation manual.
Failure to follow these instructions can result in death or injury.

⚠ WARNING

Cut/Pinch Hazard
Wear protective gear during installation, operation and service.
Edges are sharp.
Failure to follow these instructions can result in injury.

8.1 General Venting Requirements


This heater must be vented in accordance with the rules contained in this manual and with the following national codes and any state, provincial or local codes which may apply:

United States: Refer to National Fuel Gas Code NFPA 54/ANSI Z223.1 - latest revision.

Canada: Refer to Natural Gas and Propane Installation Code CSA B149.1 - latest revision.

Exhaust end of heater will accept a 4" (10 cm) vent pipe using the vent adapter (P/N 90502700). To prevent leakage of condensation, install the vent adapter with the seam on top and seal the joint using a high temperature silicone sealant.

All vent joints should be sealed using suitable product such as General Electric RTV106 or Permatex Form-a-Gasket red high temperature silicone adhesive sealant.

FIGURE 21: Outdoor Vent Cap Installation

For outdoor installations, vent caps must be installed at inlet and flue end. (See Page 37, Section 8.8).

Any portion of vent pipe passing through a combustible wall must have an approved thimble to conform with the above listed codes.

Vent pipe must be sloped downward away from the burner 1/2" (1 cm) for every 20' (6 m).

The heater may be individually vented or common vented. When venting horizontally, a maximum of two heaters can be commonly vented. See Page 39, Section 8.11. When venting vertically, a maximum of four heaters can be commonly vented. See Page 40, Section 8.12.

The heater may also be installed unvented in certain circumstances according to building ventilation codes. Refer to the above codes and Page 36, Section 8.2 for further information. Unvented operation also requires compliance with the clearances to combustibles given on Page 10, Figure 12.

The bottom of the vent or air intake terminal shall not be located less than 1' (.3 m) above grade level.

The vent shall not terminate less than 7' (2.1 m) above grade where located adjacent to public walkways.

Vent terminal must be installed at a height sufficient to prevent blockage by snow, and building materials protected from degradation by flue gases.

Secure all joints with #8 x 3/8 sheet metal screws. Seal all joints with high temperature silicone sealant.

Vent terminal must be beyond any combustible overhang.

8.1.1 United States Requirements

Vent must terminate at least 3' (.9 m) above any forced air inlet located within 10' (3.1 m).

Vent must terminate at least 4' (1.2 m) below, 4' (1.2 m) horizontally from, or 1' (.3 m) above any door, operable window, or gravity air inlet into any building.

8.1.2 Canadian Requirements

The vent shall not terminate within 6' (1.8 m) of a mechanical air supply inlet to any building.

The vent shall not terminate within 3' (.9 m) of a window or door that can be opened in any building, any non-mechanical air supply inlet to any building, or of the combustion air inlet of any other appliance.

8.2 Unvented Operation

Sufficient ventilation must be provided in the amount of 4 cfm per 1000 Btu/h firing rate (United States); 3 cfm per 1000 Btu/h firing rate (Canada).

Use of optional outside combustion air is not recommended with unvented heaters.

If exhaust fans are used to supply ventilation air, an interlock switch must be used to prevent the heater from coming on when the fans are off. This may be done using a pressure switch.

8.3 Horizontal Venting

In noncombustible walls only, vent terminal (P/N 02537801-1P) may be used.

For 4" (10 cm) vents in either combustible or noncombustible walls, use Tjernlund VH1-4 (P/N 90502100) or equivalent, insulated vent terminal. Follow the manufacturer's instructions for proper installation.

For 6" (15 cm) common vents in either combustible or noncombustible walls, use Tjernlund VH1-6 (P/N 90502101) or equivalent, insulated vent terminal. Follow the manufacturer's instructions for proper installation.

8.4 Vertical Venting

For 4" (10 cm), an approved vent cap (P/N 90502300) must be used.

For 6" (15 cm) common vent, an approved vent cap (P/N 90502302) must be used.


For common vertical venting of more than two heaters, See *Page 40, Section 8.12*.

A vent shall not extend less than 2' (.6m) above the highest point where it passes through a flat roof of a building.

8.5 Unvented Operation Tube Termination

Turndown type vent terminal with a screen must be installed at the exhaust end of the tube. Vent terminal design shall not incorporate backdraft flap.

FIGURE 22: Tube Termination



8.6 Length Requirements

The maximum vent length allowed is 45' (13.7 m). The maximum outside air supply duct length allowed is 45' (13.7 m).

The total vent length, plus outside air duct length, plus any extensions to minimum heat exchanger lengths, cannot exceed 65' (19.8 m).

Vent length should be limited to less than 20' (6 m). If using vent lengths greater than 20' (6 m), condensation will form in the vent pipe. Insulation and additional sealing measures (high temperature silicone at all seams) are required. Optional heat exchanger beyond minimum lengths is considered as vent length for length determination.

Subtract 15' (4.6 m) of maximum allowed vent or duct length per vent elbow if more than two are used.

8.7 Vent Material Recommendations


Vent recommendations:

1. Porcelain coated tubing 4" (10 cm) O.D. (P/N 9141030D)
2. Heat treated aluminized tubing 4" (10 cm) O.D. (P/N 91409408)
Heat treated aluminized tubing 6" (15 cm) O.D. (P/N E0009105)

Single wall flue pipe - minimum 26 ga.
(Supplied by others)

NOTE: 4" (10 cm) O.D. Porcelain coated tubing (P/N 914030D), 4" (10 cm) O.D. Heat treated aluminized tubing (P/N 91409408), and 6" (15 cm) O.D. Heat treated aluminized tubing (P/N E0009105) are equivalent to single wall flue pipe.

8.8 Venting Options



8.9 Horizontal Ventilation 4" (10 cm) Pipe

Non-Combustible Wall Only

Combustible or Non-Combustible Wall

SIDE VIEW

Description	Part Number
Vent Terminal (Comb. Wall)	90502100
Vent Terminal	02537801-XX
Vent Cap 4" (10 cm)	90502300


8.10 Vertical Ventilation 4" (10 cm) Pipe

SIDE VIEW

The last section of vent pipe passing through the roof or wall may be Type "B" vent pipe. All other vent materials in the building must be single wall vent pipe.

Description	Part Number
Vent Cap 4" (10 cm)	90502300


8.11 Common Sidewall Venting



Requirements:

- Maximum of two heaters can be commonly vented through a side wall.
- Heaters must be of the same BTU output.
- Heaters must be controlled by a common thermostat.

8.12 Common Vertical Venting



Requirements:

- Maximum of four heaters can be commonly vented through the roof.
- Heaters must be of the same BTU output.
- Heaters must be controlled by a common thermostat.
- Connections to a common stack must be positioned to avoid direct opposition between streams of combustion gases.

8.13 Outside Combustion Air Supply

IMPORTANT: If the building has a slight negative pressure or corrosive contaminants, such as halogenated hydrocarbons, are present in the air, an outside combustion air supply to the heater is required. Seal all combustion air pipe joints.

Use of optional outside combustion air is not recommended with unvented heaters.


The air supply duct may have to be insulated to prevent condensation on the outer surface. The outside air terminal must not be more than 1' (31 cm) above the vent termination while maintaining a minimum distance of 3' (93 cm) for both vertical and

horizontal venting.

8.13.1 Length Requirements


Follow the constraints listed on *Page 36, Section 8.6.*

8.13.2 Vertical Outside Air Supply for Single Heater Installation




Description	Part Number
Vent Cap 4" (10 cm)	90502300

8.13.3 Horizontal Outside Air Supply for Single Heater Installation



Description	Part Number
Vent Cap 4" (10 cm)	90502300


8.13.4 Vertical Outside Air Supply for Double Heater Installation



Requirements:

- Heaters must be controlled by a common thermostat.

8.13.5 Horizontal Outside Air Supply for Double Heater Installation



Requirements:

- Heaters must be controlled by a common thermostat.

SECTION 9: GAS PIPING

⚠ WARNING**Fire Hazard**

Tighten gas hose fittings to connect gas supply according to Figure 23.

Gas hose can crack when twisted.

Gas hose moves during normal operation.

Use only 36" (91 cm) long connector of 1/2" or 3/4" nominal ID.

Connector supplied with heater for U.S. models (not with Canadian models).

Failure to follow these instructions can result in death, injury or property damage.

⚠ WARNING**Explosion Hazard**

Leak test all components of gas piping before operation.

Gas can leak if piping is not installed properly.

Do not high pressure test gas piping with heater connected.

Failure to follow these instructions can result in death, injury or property damage.

There is an expansion of the tube with each firing cycle, this will cause the burner to move with respect to the gas line. This can cause a gas leak resulting in an unsafe condition if the gas connection is not made strictly in accordance with *Figure 23*.

Meter and service must be large enough to handle all the burners being installed plus any other connected load. The gas line which feeds the system must be large enough to supply the required gas with a maximum pressure drop of 1/2" wc. When gas piping is not included in the layout drawing, the local gas supplier will usually help in planning the gas piping.

Gas lines must meet applicable codes:

United States: The Flexible Stainless Steel Gas Hose (US models) supplied with the heater is certified per the Standard for Connectors for Gas Appliances, ANSI Z21.24/CSA 6.10 - latest revision.

Canada: The Rubber Type 1 Gas Hose (Canadian models) optional with the heater is certified as being in compliance with the Standard for Elastomeric Composite Hose and Hose Couplings for Conducting Propane and Natural Gas, CAN/CGA 8.1 - Latest revision.

- **Check the pipe and tubing ends for leaks before placing heating equipment into service. When checking for gas leaks, use a soap and water solution; never use an open flame.**


Install the gas hose as shown in *Figure 23*. The gas hose accommodates expansion of the heating system and allows for easy installation and service of the burner. Before connecting the burners to the supply system, verify that all high pressure testing of the gas piping has been completed.

FIGURE 23: Gas Connection with Flexible Gas Hose

CORRECT POSITIONS

Shut-Off Valve (included with gas hose) must be parallel to burner gas inlet. The 3" (8 cm) displacement shown is for the cold condition. This displacement may reduce when the system is fired.

High Gas Pressure Regulator to be installed upstream of flexible gas hose if inlet pressure exceeds maximum allowance. See Page 60, Section 14.




! CAUTION


Product Damage Hazard

Hold gas nipple securely with pipe wrench when attaching gas hose.

Failure to follow these instructions can result in product damage.



INCORRECT POSITIONS (WRONG INSTALLATION)



Description	Part Number
3/4" Flexible Stainless Steel Gas Hose (US Models)	91412204
3/4" Rubber Type 1 Gas Hose (Canadian Models)	91412207

SECTION 10: WIRING

⚠ DANGER



Electrical Shock Hazard


Disconnect electric before service.

Heater must be properly grounded.


Failure to follow these instructions can result in death or electrical shock.

Heaters can be controlled using several methods. Normally thermostats are used to control the heaters but they can also be controlled by an Energy

10.1 Line Voltage Thermostat Wiring




10.2 Low Voltage Thermostat with One Burner




Management System. *Section 10.1* below illustrates the connection for heaters controlled by a line voltage thermostat. NOTE: In order to use line voltage thermostats, the low voltage terminal located at the back of each burner must be connected as shown in the detail. For a single heater on a low voltage thermostat, See *Section 10.2* below. To control multiple heaters on one low voltage thermostat, See *Page 46, Section 10.3*. NOTE: In order to control multiple heaters on one low voltage thermostat, the low voltage terminals on each heater must be connected as shown in detail. Heaters must be grounded in accordance with applicable codes: United States: refer to National Electrical Code® ANSI/NFPA 70 - latest revision Canada: refer to Canadian Electrical Code CSA C22.1 Part I - latest revision.

If any of the original internal wiring must be replaced, it must be replaced with wiring materials having a temperature rating of at least 105° C and 600 V.

10.3 Low Voltage Thermostat Wiring with Multiple Burners



10.4 Electrical Connection to the Burner Box using Line Voltage Thermostat on Control




10.5 For External Thermostat Connection


Run two wires from low voltage thermostat through conduit as shown. The purple wire from the valve and the blue wire from the transformer have 1/4" (6 mm) blade female electrical terminals, which are connected by a black jumper wire. Cut the female

connections off the ends of the blue and purple wires and strip the ends approximately 1/2" (1.3 cm). Connect these 2 wires to the thermostat wires using suitable wire connectors.


10.6 Electrical Connection to Burner Box with Optional External Low Voltage Thermostat







10.7 Internal Wiring



10.8 Ladder Diagram



SECTION 11: OPERATION AND MAINTENANCE

⚠ DANGER		⚠ WARNING	
			
Electrical Shock Hazard Disconnect electric before service. Heater must be connected to a properly grounded electrical source.	Explosion Hazard Turn off gas supply to heater before service.	Burn Hazard Allow heater to cool before service. Tubing may still be hot after operation.	Cut/Pinch Hazard Wear protective gear during installation, operation and service. Edges are sharp.
Failure to follow these instructions can result in death, electric shock, injury or property damage.			

The heater is equipped with a hot-surface ignition system.

11.1 Sequence of Operation

- Turn the thermostat up. When the thermostat calls for heat, the SmartValve® II will energize. After a short period, power is supplied to the blower motor.
- When the motor approaches nominal running RPM, the pressure switch closes and signals the ignition module/SmartValve® II.
- The ignition module/SmartValve® II then energizes the hot-surface igniter for a timed warm-up period (approximately 45 to 60 seconds). After the warm-up period, the gas valve is energized.
- If a flame is detected, the gas valve remains open and the igniter is de-energized. When the call for heat is satisfied, and the system control mechanism de-energizes the burner line voltage supply, the gas is turned off.
- If no flame is detected by the flame sensing rod, the igniter is de-energized and the module/SmartValve® II will close and a purge period begins. After the purge, the module/SmartValve® II acts to power the igniter for a second warm-up period and a second trial for ignition period. If flame is still not established, a third purge, warm-up, and trial cycle begins. After four trials,

the module/SmartValve® II will lockout for one hour or until reset.

- If the flame extinguishes during operation, the igniter module will provide multiple trial sequences described in step 5. If ignition is not re-established, the module/SmartValve® II will lockout for one hour or until reset.
- After lockout, reset by turning down thermostat for five seconds, and then raising it again to desired temperature, or by disconnecting power and then reconnecting.

11.2 To Shut Off Heater

Set thermostat to lowest setting.

Turn OFF electric power to heater.

Turn OFF manual gas valve in the heater supply line.

11.3 To Start Heater

Turn gas valve and electric power OFF and wait five minutes for unburned gases to vent from heater.

Turn ON main gas valve.

Turn ON electric power.

Set thermostat to desired temperature. Burner should light automatically.

11.4 Pre-Season Maintenance and Annual Inspection

To ensure your safety and years of trouble-free oper-

ation of the heating system, service and annual inspections must be done by a contractor qualified in the installation and service of gas-fired heating equipment.

Turn off gas and electric supplies before performing service or maintenance. Allow heater to cool before servicing.

Before every heating season, a contractor qualified in the installation and service of gas-fired heating equipment must perform a thorough safety inspection of the heater.

For best performance, the gas, electrical, thermostat connections, tubing, venting, suspensions and overall heater condition should be thoroughly inspected.

NOTE: Gas flow and burner ignition are among the first things that should be inspected.

Please see *Page 50, Section 11.5* for suggested items to inspect.

11.5 Maintenance Checklist

The Vicinity of the Heater	Do not store or use flammable objects, liquids or vapors near the heater. Immediately remove these items if they are present. <i>See Page 6, Section 3.</i>
Vehicles and Other Objects	<p>Maintain the clearances to combustibles.</p> <p>Do not hang anything from, or place anything on, the heater.</p> <p>Make sure nothing is lodged underneath the reflector, in between the tubes or in the decorative or protective grilles (included with select models).</p> <p>Immediately remove objects in violation of the clearances to combustibles.</p> <p><i>See Page 6, Section 3.</i></p>
Reflector	<p>Support reflector with reflector hanger and support strap.</p> <p>Reflector must not touch tube.</p> <p>Make sure there is no dirt, sagging, cracking or distortion.</p> <p>Do not operate if there is sagging, cracking or distortion.</p> <p>Make sure reflectors are correctly overlapped. <i>See Page 24, Section 6.6.1.</i></p> <p>Clean any debris from top and surface of reflectors with a damp cloth.</p> <p>Check for evidence of animals such as squirrels or birds and remove any nests prior to firing.</p>
Vent Pipe	<p>Venting must be intact. Using a flashlight, look for obstructions, cracks on the pipe, gaps in the sealed areas or corrosion.</p> <p>The area must be free of dirt and dust.</p> <p>Remove any carbon deposits or scale using a wire brush.</p> <p>Check for evidence of animals such as squirrels or birds and remove any nests prior to firing. <i>See Page 35, Section 8.</i></p>
Outside Air Inlet	<p>Inlet must be intact. Look for obstructions, cracks on the pipe, gaps in the sealed areas or corrosion.</p> <p>The area must be free of dirt and dust. Clean and reinstall as required.</p>


Installation Code and Annual Inspections:





All installation and service of ROBERTS GORDON® equipment must be performed by a contractor qualified in the installation and service of equipment sold and supplied by Roberts-Gordon LLC and conform to all requirements set forth in the ROBERTS GORDON® manuals and all applicable governmental authorities pertaining to the installation, service, operation and labeling of the equipment.

To help facilitate optimum performance and safety, Roberts-Gordon LLC recommends that a qualified contractor conduct, at a minimum, annual inspections of your ROBERTS GORDON® equipment and perform service where necessary, using only replacement parts sold and supplied by Roberts-Gordon LLC.

Reflector Support Straps	<p>Verify that the reflector support straps are securely clamped to tube and reflector. <i>See Page 24, Step 6.6.1.</i></p> <p>Verify tight and loose screws at reflector overlaps.</p>
Tubes	<p>Make sure there are no cracks.</p> <p>Make sure tubes are connected and suspended securely.</p> <p><i>See Page 15, Section 6.</i></p> <p>Make sure there is no sagging, bending or distortion.</p> <p>Clean any debris from top of tubes or replace as required.</p> <p>Check the inside of the firing tube with a flashlight. If carbon or scale are present remove the turbulator(s). Scrape out the deposits with a wire brush or rod, or metal plate attached to a wooden pole and replace turbulator(s) in tube.</p> <p>Check for evidence of animals such as squirrels or birds and remove any nests prior to firing.</p>
Gas Line	<p>Check for gas leaks. <i>See Page 43, Section 9.</i></p>
Burner Observation Window	<p>Make sure it is clean and free of cracks or holes.</p> <p>Clean and replace as required.</p>
Drain Hole	<p>Be sure that the drain hole in the bottom of the burner compartment is not blocked or clogged.</p>
Blower Scroll, Wheel and Motor	<p>Compressed air or a vacuum cleaner may be used to clean dust and dirt.</p>
Burner Cup and Orifice	<p>Clear of obstructions (even spider webs will cause problems).</p> <p>Carefully remove any dust and debris from the burner.</p>
Hot-Surface Igniter	<p>Replace if cracked or broken.</p>
Thermostat	<p>There should be no exposed wire or damage to the thermostat.</p> <p><i>See Page 45, Section 10.</i></p>
Suspension Points	<p>Make sure the heater is hanging securely. Look for signs of wear on the chain or ceiling.</p> <p><i>See Page 16, Figure 14.</i></p>
Decorative and Protective Grille (optional)	<p>The grille must be securely attached.</p> <p>Check that the side reflector extensions are installed correctly and secured in place if necessary (Decorative grille only).</p> <p><i>See Page 32, Section 7.5 and Page 34, Section 7.6</i></p> <p>Make sure shield is installed correctly and secured in place if necessary. (Decorative grille only.) <i>See Page 33, Section 7.5.2.</i></p>
Lower Clearance Shield (optional)	<p>The lower shield must be securely attached. Inspect shield support straps and lower clearance shield anchor points. <i>See Page 32, Section 7.4.</i></p> <p>Make sure shield is installed correctly and secured in place if necessary.</p> <p><i>See Page 32, Section 7.4.</i></p>
Wall Tag	<p>If wall tag is present, make sure it is legible and accurate. Please contact Roberts-Gordon LLC or your ROBERTS GORDON® independent distributor, if you need a wall tag. <i>See Page 4, Section 2.1.</i></p>
Safety Labels	<p>Product safety signs or labels should be replaced by the product user when they are no longer legible. Please contact Roberts-Gordon LLC or your ROBERTS GORDON® independent distributor to obtain replacement signs or labels. <i>See Page 1, Figure through Page 3, Figure 2.</i></p>

SECTION 12: TROUBLESHOOTING

⚠ DANGER

Electrical Shock Hazard
<p>Disconnect electric before service.</p> <p>Heater must be properly grounded.</p> <p>Failure to follow these instructions can result in death or electrical shock.</p>

⚠ WARNING			
			
Fire Hazard	Explosion Hazard	Burn Hazard	Cut/Pinch Hazard
<p>Keep all flammable objects, liquids and vapors the minimum required clearances to combustibles away from heater.</p> <p>Some objects will catch fire or explode when placed close to heater.</p>	<p>Turn off gas supply to heater before service.</p>	<p>Allow heater to cool before service.</p> <p>Tubing may still be hot after operation.</p>	<p>Wear protective gear during installation, operation and service.</p> <p>Edges are sharp.</p>
Failure to follow these instructions can result in death, injury or property damage.			

12.1 Honeywell SmartValve® II Troubleshooting

This heater is supplied with the Honeywell SmartValve® II control system. This system is equipped with a diagnostic function that will assist in performing troubleshooting. The LED (Light Emitting Diode) indicator at the top of the SmartValve® II control will flash in various patterns to indicate status. The LED status indication chart provided below gives a summary of possible faults.

LED Status	Indicates
Off	No power to the control
Bright-Dim	Normal Operation. This indication shows whenever the system is powered, unless some abnormal event has occurred.
2 Flashes	Pressure switch remains closed longer than 30 seconds after a call for heat begins (pressure switch stuck closed). The SmartValve® II checks the status of the pressure switch contacts and must see a change in the contact with every firing cycle. Placing a jumper at the switch out of sequence will result in a fault, with the LED indicator flashing 2 times.
3 Flashes	Pressure switch remains open longer than 30 seconds after combustion air blower is energized. Check for correct blower operation, blower intake obstructions, pressure switch tubing and wiring.
4 Flashes	Limit string open, 2" white jumper wire on valve is loose.
5 Flashes	Flame signal sensed out of proper sequence.
6 Flashes	System Lockout. Flame sensing circuit is not functioning properly. Perform the checks following the "Does the burner stay lit?" bubble in the troubleshooting flow chart on Page 54, Section 12.2.

WARNING



Electrical Shock Hazard


Do not disconnect ground leads inside heater.


Do not interchange grounded and ungrounded leads on transformer or ignition module.

Failure to follow these instructions can result in death or electrical shock.


Page 56, Section 12.3 will provide the information needed to test the manifold gas pressure setting. Page 54, Section 12.2 will guide you through several troubleshooting steps to determine possible problems with the systems.

12.2 Troubleshooting Flow Chart










12.3 Manifold Gas Pressure Setting



SECTION 13: REPLACEMENT PARTS

⚠ DANGER	⚠ WARNING		
			
Electrical Shock Hazard	Explosion Hazard	Fire Hazard	Carbon Monoxide Hazard
Use only genuine ROBERTS GORDON® replacement parts per this installation, operation and service manual.			
Failure to follow these instructions can result in death, electric shock, injury or property damage.			

See warnings and important information before removing or replacing parts. After any maintenance or repair work, always test fire the heater in accordance with the start-up instructions *on Page 49, Section 11* to help ensure all safety systems are in working order before leaving the heater to operate. Minor faults may be traced by using the troubleshooting charts *on Page 52, Section 12 through Page 54, Figure 12.2*.



Description	Part Number
Gas Valve (Natural)	90068300
Gas Valve (LP)	90068302
Tube Gasket	02568200
Blower Inlet Gasket	03050900
Motor and Blower Assembly	90708600-P
Air Adapter Collar	91911700
Door Switch	90436800
Burner Cup Assembly	03020100
Hot Surface Igniter	90436603K
Mica Window Assembly	02553203
Flame Sensor	90439300
Transformer	90436900K
Gasket - Valve	03200100
Pressure Switch:	
(175)	90439802K
(100)	90439803K
(80,150)	90439810K
(40, 60, 125)	90439805K

SECTION 14: GENERAL SPECIFICATIONS

14.1 Material Specifications

14.1.1 Reflectors

.024 Aluminum or .024 Stainless Steel Type 304

14.2 Heater Specifications

14.2.1 Ignition

Honeywell® SmartValve® II combines gas valve and hot surface electronic ignition control. Fully automatic, four-try, 100% shut-off, prepurge, auto reset, LED indicator status.


14.3 Suspension Specifications

Hang heater with materials with a minimum working load of 75 lbs (33 kg). See Page 16, Figure 14.

14.4 Controls Specifications

Time switches, thermostats, etc. can be wired into the electrical supply. External controls supplied as an optional extra.

General Specifications for the heaters are as follows:



*See Page 6, Section 3 for clearances to combustibles. Recommended mounting height for outdoor use will generally be lower than recommended spot heating heights, (8' (2.3 m) minimum).

GAS PRESSURE AT MANIFOLD:

Natural Gas: 3.5" wc

LP Gas: 10.5" wc

PIPE CONNECTION:

3/4" NPT

DIMENSIONS:

Vent Connection Size: 4" (10 cm)

Outside Air Connection Size: 4" (10 cm)

Refer to figure above for dimensional information.

GAS INLET PRESSURE:

Natural Gas:

for 40,60,80,100,125,150 4.6" wc Minimum

for 175 5.0" wc Minimum

14.0" wc Maximum

LP Gas: 11.0" wc Minimum

14.0" wc Maximum

ELECTRICAL RATING (ALL MODELS):

120V - 60 Hz., 1.0 A (run) 5.0 A (Start)

SECTION 15: THE ROBERTS GORDON® VANTAGE® HE WARRANTY

ROBERTS-GORDON LLC WILL PAY FOR:

Within 36 months from date of purchase by buyer or 42 months from date of shipment by Roberts-Gordon LLC (whichever occurs first), replacement parts will be provided free of charge for any part of the product which fails due to a manufacturing or material defect.

Roberts-Gordon LLC will require the part in question to be returned to the factory. Roberts-Gordon LLC will, at its sole discretion, repair or replace after determining the nature of the defect and disposition of part in question.

ROBERTS GORDON® Replacement Parts are warranted for a period of 12 months from date of shipment from Roberts-Gordon LLC or the remaining ROBERTS GORDON® VANTAGE® HE warranty.

ROBERTS-GORDON LLC WILL NOT PAY FOR:

Service trips, service calls and labor charges.

Shipment of replacement parts.

Claims where the total price of the goods have not been paid.

Damage due to:

- Improper installation, operation or maintenance.
- Misuse, abuse, neglect, or modification of the ROBERTS GORDON® VANTAGE® HE in any way.
- Use of the ROBERTS GORDON® VANTAGE® HE for other than its intended purpose.
- Incorrect gas or electrical supply, accident, fire, floods, acts of God, war, terrorism, or other casualty.
- Improper service, use of replacement parts or accessories not specified by Roberts-Gordon.
- Failure to install or maintain the ROBERTS GORDON® VANTAGE® HE as directed in the Installation, Operation and Service manual.
- Relocation of the ROBERTS GORDON® VANTAGE® HE after initial installation.
- The use of the ROBERTS GORDON® VANTAGE® HE in a corrosive atmosphere containing contaminants.
- The use of the ROBERTS GORDON® VANTAGE® HE in the vicinity of a combustible or explosive material.
- Any defect in the ROBERTS GORDON® VANTAGE® HE arising from a drawing, design, or specification supplied by or on behalf of the consumer.
- Damage incurred during shipment. Claim must be filed with carrier.

WARRANTY IS VOID IF:

The ROBERTS GORDON® VANTAGE® HE is not installed by a contractor qualified in the installation and service of gas fired heating equipment.

You cannot prove original purchase date and required annual maintenance history.

The data plate and/or serial number are removed, defaced, modified or altered in any way.

The ownership of the ROBERTS GORDON® VANTAGE® HE is moved or transferred. This warranty is nontransferable.

Roberts-Gordon LLC is not permitted to inspect the damaged equipment and/or component parts

READ YOUR INSTALLATION, OPERATION AND SERVICE MANUAL

If you have questions about your equipment, contact your installing professional. Should you need Replacement Parts or have additional questions, call or write:

Roberts-Gordon LLC

1250 William Street

P.O. Box 44

Buffalo, New York 14240-0044

Telephone: +1.716.852.4400

Fax: +1.716.852.0854

Toll Free: 800.828.7450

www.robertsgordon.com

Roberts-Gordon LLC's liability, and your exclusive remedy, under this warranty or any implied warranty (including the implied warranties of merchantability and fitness for a particular purpose) is limited to providing replacement parts during the term of this warranty. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you. There are no rights, warranties or conditions, expressed or implied, statutory or otherwise, other than those contained in this warranty.

Roberts-Gordon LLC shall in no event be responsible for incidental or consequential damages or incur liability for damages in excess of the amount paid by you for the ROBERTS GORDON® VANTAGE® HE. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction.

Roberts-Gordon LLC shall not be responsible for failure to perform under the terms of this warranty if caused by circumstances out of its control, including but not limited to war, fire, flood, strike, government or court orders, acts of God, terrorism, unavailability of supplies, parts or power. No person is authorized to assume for Roberts-Gordon LLC any other warranty, obligation or liability.

LIMITATIONS ON AUTHORITY OF REPRESENTATIVES:

No representative of Roberts-Gordon LLC, other than an Executive Officer, has authority to change or extend these provisions. Changes or extensions shall be binding only if confirmed in writing by Roberts-Gordon LLC's duly authorized Executive Officer.

OWNER WARRANTY REGISTRATION CARD

Mail or Fax to:

Roberts Gordon LLC • 1250 William Street, P.O. Box 44 • Buffalo, NY 14240-0044 • Phone: 716-852-4400 • Fax: 716-852-0854
Toll Free: 800-828-7450 • www.robertsgordon.com

About the Owner:

Name: _____
Address: _____ City: _____ State: _____ Zip Code: _____
Phone: _____ Fax: _____ E-mail: _____

About the Installer:

Name: _____
Address: _____ City: _____ State: _____ Zip Code: _____
Phone: _____ Fax: _____ E-mail: _____

Purchased From (if different than installer):

Name: _____
Address: _____ City: _____ State: _____ Zip Code: _____
Phone: _____ Fax: _____ E-mail: _____

About your Heater:

Model#: _____ Serial #: _____ Fuel: _____ Installation Date: _____

Type of Installation (check one):

Automotive Manufacturing Warehouse Recreational Aircraft
 Public Building Office Retail Agricultural Other _____

Installation Code and Annual Inspections: All installation and service of ROBERTS GORDON® equipment must be performed by a contractor qualified in the installation and service of equipment sold and supplied by Roberts-Gordon LLC and conform to all requirements set forth in the ROBERTS GORDON® manuals and all applicable governmental authorities pertaining to the installation, service, operation and labeling of the equipment.

To help facilitate optimum performance and safety, Roberts-Gordon LLC recommends that a qualified contractor conduct, at a minimum, annual inspections of your ROBERTS GORDON® equipment and perform service where necessary, using only replacement parts sold and supplied by Roberts-Gordon LLC.

These products are not for residential use.

This product is intended to assist licensed professionals in the exercise of their professional judgment.

© 2015 Roberts-Gordon LLC - All rights reserved. No part of this work covered by the copyrights herein may be reproduced or copied in any form or by any means – graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems – without written permission of Roberts Gordon LLC.
Printed in the U.S.A.

Attach this information to a wall near the ROBERTS GORDON® heater.

ROBERTS GORDON®

Infrared Heating

Read the Installation, Operation, and Service Manual thoroughly before installation, operation, or service.

Know your model number and installed configuration.

Model number and installed configuration are found on the burner and in the Installation, Operation and Service Manual.

Write the largest clearance dimensions with permanent ink according to your model number and configuration in the open spaces below.

OPERATING INSTRUCTIONS

1. STOP! Read all safety instructions on this information sheet.
2. Open the manual gas valve in the heater supply line.
3. Turn on electric power to the heater.
4. Set the thermostat to desired setting.

TO TURN OFF THE HEATER

1. Set the thermostat to off or the lowest setting.

IF THE HEATER WILL NOT OPERATE, TO ENSURE YOUR SAFETY, FOLLOW THESE INSTRUCTIONS TO SHUT DOWN YOUR HEATER

1. Set the thermostat to off or the lowest setting.
2. Turn off electric power to the heater.
3. Turn off the manual gas valve in the heater supply line.
4. Call your registered installer/contractor qualified in the installation and service of gas-fired heating equipment.

⚠ WARNING



Fire Hazard

Keep all flammable objects, liquids and vapors the minimum required clearances to combustibles away from heater.

Some objects will catch fire or explode when placed close to heater.

Failure to follow these instructions can result in death, injury or property damage.

Maintain _____ clearance
to the side and
_____ clearance below
the heater from vehicles
and combustible materials.

Roberts-Gordon LLC
1250 William Street
P.O. Box 44
Buffalo, NY 14240-0044 USA
Telephone: +1.716.852.4400
Fax: +1.716.852.0854
Toll Free: 800.828.7450

Installation Code and Annual Inspections:

All installation and service of ROBERTS GORDON® equipment must be performed by a contractor qualified in the installation and service of equipment sold and supplied by Roberts-Gordon and conform to all requirements set forth in the ROBERTS GORDON® manuals and all applicable governmental authorities pertaining to the installation, service, operation and labeling of the equipment. To help facilitate optimum performance and safety, Roberts-Gordon recommends that a qualified contractor conduct, at a minimum, annual inspections of your ROBERTS GORDON® equipment and perform service where necessary, using only replacement parts sold and supplied by Roberts-Gordon.

Further Information: Applications, engineering and detailed guidance on systems design, installation and equipment performance is available through ROBERTS GORDON® representatives. Please contact us for any further information you may require, including the Installation, Operation and Service Manual.

This product is not for residential use.

© 2015 Roberts-Gordon LLC All rights reserved. No part of this work covered by the copyrights herein may be reproduced or copied in any form or by any means – graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems – without written permission of Roberts-Gordon LLC.

www.robertsgordon.com

P/N 91037912 Rev. K