

# InfraRay™ Modulating Controller – Zone Schedule

MENU

PANEL 1 SCHEDULE- ZONE 1

ROBERTS GORDON

	Enable	Start Time	Stop Time
Sunday	<input type="radio"/>	07 : 00	17 : 00
Monday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Tuesday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Wednesday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Thursday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Friday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Saturday	<input type="radio"/>	07 : 00	17 : 00

To maximize comfort and system performance, it is recommended to program your heating schedule in accordance with your occupied and unoccupied zones and schedule. For best results, keep your night setback temperature within 5 °F to 8 °F of your occupied setpoint temperature. In the Home screen select **Zone Schedule** for a list of weekdays and **Start Time** and **Stop Time**. Program each zone.

The default schedule is Monday to Friday, 7 am to 5 pm. By clicking on each day, the user can enable or disable the specific day and set the start and stop times.

To maximize comfort and system performance, it is recommended to program your heating schedule in accordance with your occupied and unoccupied zones and schedule.

MENU

PANEL 1 SCHEDULE- ZONE 1

ROBERTS GORDON

	Enable	Start Time	Stop Time
Sunday	<input type="checkbox"/>	07 : 00	17 : 00
Monday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Tuesday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Wednesday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Thursday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Friday	<input checked="" type="checkbox"/>	07 : 00	17 : 00
Saturday	<input type="checkbox"/>	07 : 00	17 : 00